



Installation Instructions

Instructions for Connecting PETROSMART EZ Control Systems to Bennett 3K series Electronic Dispensers Without CREDIT CARD MODULES

Read This Book

This book has important information for safe installation and operation of this equipment. Read and understand this book before applying power. Keep this book and tell all service personnel to read this book. **If you do not follow the instructions, you can cause damage to the equipment, injury, or death.**

Triangle MicroSystems Inc.
2716 Discovery Drive
Raleigh, N.C. 27616
(919) 878-1880
<http://www.trianglemicrosystems.net>

PetroSmart EZ Control System

Table of Contents

SECTION	Page
Dangers Warnings and Precautions	Pg. 3
System Requirements	Pg. 4
System Description	Pg. 4
PetroSmart EZ System Diagram	Pg. 5
Bennett Dispenser Control Interconnect Box	Pg. 7
Connection of Dispenser Control Data Wires	Pg. 8
PetroSmart EZ Converter Board	Pg. 9
Power Requirements	Pg. 10
Cable Connections	Pg. 11
Important Notes	Pg. 12
Specifications	Pg. 13
TMS Service and Warranty Information	Pg. 14-15

Dangers, Warnings and Precautions

FOR THE SAFE INSTALLATION, MAINTENANCE, AND OPERATION OF THIS CONSOLE AND RELATED EQUIPMENT, READ AND UNDERSTAND ALL WARNINGS AND CAUTIONS.

"DANGER": means: If you do not follow the instructions, severe injury or death will occur.

"WARNING": means: If you do not follow the instructions, severe injury or death can occur.

"CAUTION": means: If you do not follow the instructions, damage can occur to the equipment.

"DANGER": Disconnect all power to this equipment and associated dispenser's equipment during installation, service or any maintenance. Failure to do so can cause injury or damage equipment.

"WARNING": QUALIFIED/TRAINED personnel must do Maintenance and repairs.

"WARNING": To prevent electric shock, keep the electrical parts of the console dry.

"WARNING": You must have training in the installation and service of fuel dispensing equipment before working on this system.

"WARNING": Make sure this equipment is correctly grounded. Failure to do so can cause injury or damage equipment.

"CAUTION": Electronic components are static sensitive. Use proper static precautions (static straps) before working on the equipment.

"WARNING": Failure to properly ground all equipment can cause injury or damage equipment.

"WARNING": Installation must comply with National Code (NFPA #70), Automotive and Marine Service Code (NFPA #30A), Federal, State and local codes.

"CAUTION": This equipment generates and uses radio frequency energy. If not installed and used properly, i.e., in strict accordance with the instructions in this manual, it may cause interference to radio communications. The console was tested and found to comply with the limits for a Class-A computing device in accordance with Sub-part J of Part 15 of the FCC Rules. A Class-A computing device is designed to provide reasonable protection against interference when operated in commercial environment.

"CAUTION": Follow proper grounding procedures to reduce radio frequency interference (RFI). Ground each piece of equipment connected to, or controlled by, the console to the electrical service panel ground.

"CAUTION": Each dispenser must have a 12 gauge or larger green stranded ground wire connected from the grounding lug of the junction box to the main electrical service panel ground. (National Electrical Code, Article 514-7). It is unacceptable to rely on the conduit for this grounding requirement.

System Requirements

In developing the Triangle MicroSystems control system for Bennett dispensers, Bennett provided the communication protocols that required separate data wires for each dispenser. This is Bennett standard policy for “third party” control systems. Secondly, the TMS control system does not require the Bennett interface box to interface with the dispensers. The dispenser control data wires connect directly from the 3K-dispenser junction box to the EZ 85 IC box. The data wires from the dispensers to the IC Box should be a shielded, single twisted pair conductor to avoid electrical noise interfering with communication.

Installations will vary from site to site in terms of the electrical interference induced into the dispenser data wires. The cable shield when connected to the ground screw on the TMS PetroSmart interface power supply will significantly reduce the electrical interference.




Fig. 1, PetroSmart Data Wire Diagram

PETROSMART EZ System Description

The PETROSMART EZ fuel control system for BENNETT electronics was designed to control 3K series electronic dispensers without credit card modules.

The PETROSMART EZ dispenser control system is comprised of the following items:

Qty.	Description
1	PETROSMART EZ Console.
1	PETROSMART EZ Bennett dispenser control IC box.
2	PETROSMART EZ cables. 1– 25', Console to IC Box 1-- 3', IC Box to IC Box
An Optional	UPS (Uninterruptible Power Supply) is recommended

Fueling Positions

The maximum number of fueling positions permissible is 8 for a PETROSMART EZ-8 or 16 for a PETROSMART EZ-16, where each side of an MPD (no matter how many grades) counts as one fueling position.

PetroSmart EZ System Diagram





Fig. 2, PetroSmart EZ System Diagram

Dispenser Control Interconnect Box



Note: All IC boxes come with the 24" cable connected.

Fig. 3 Typical PetroSmart EZ IC Box.




Fig. 4, The PetroSmart EZ Bennett Dispenser Control Box with the Door Open. **NOTE: This figure shows INCORRECT CABLE CONNECTION between the front and back pan. Figure 3 shows correct connection after the IC Box has been closed.**

The PETROSMART EZ Bennett dispenser IC box includes the EZ TM85 communication board and the EZ-E-CONV converter board.

The EZ TM85 communication board/power supply receives the incoming line voltage (120 VAC), supplies the operating system with DC voltage. The dispenser IC box transmits data signals between the console and the dispenser.

Connection of Dispenser Control, Data Wires




Fig. 5, Dispenser Control EZ TM85 Board

Connect the dispenser control wires to the (+) and (-) data terminals. A communication FAIL error will display if the polarity should be reversed when making connections, but will not damage the board.

PETROSMART EZ Converter Board




Fig. 6, PETROSMART EZ Converter Board

The converter board is located on the inside cover of both the dispenser control IC box; refer to Figure 4 on page 7.

IMPORTANT After installation of IC box, check the slide switch on the converter board (Refer to Fig. 10) for the proper switch position. In the IC box that is connected to the dispenser data wires the slide switch must be positioned on the end marked "GAS PUMP".

Power Requirements

CONNECTION INSTRUCTIONS FOR THE SYSTEM POWER SUPPLY, DISPENSER, MOTOR, AND ELECTRICAL GROUND CIRCUITS

A.C. POWER REQUIREMENTS

1. Breaker Panel: A 125 Amp breaker is the minimal allowable electrical service for the pump motor and interface boxes, dispensers, canopy lights and advertising signs.
2. IC boxes: Both the dispenser IC box and the DPT credit card module IC box require a 115VAC, 15 Amp DEDICATED breaker (with no other devices or outlets connected to it) for connection to the EZ TM85 board, and to the MPC-TM85 board. Make sure the correct voltage and frequency are present. All AC wires must be 14 gauge (min.), and in conduit. Do not put wiring from other sources in this conduit.
3. PETROSMART EZ Console: a standard plug-in AC Adaptor power module powers the console. The Adaptor can be inserted into a standard electrical outlet that supplies, 115VAC, 60Hz, and 15W power. The Adaptor converts the input to 15 VDC, 600mA that it supplies to the EZ console. A UPS is supplied with then system to minimize disruption in the event of a general power failure.
4. Dispensers: The dispensers' installation guide shows all requirements including, but not limited to breakers, wires to supply data signals to the electronics, green wire for Earth Ground, and wires to power the dispenser and fluorescent lighting. Refer to the installation manual for the dispenser being installed for complete installation requirements.

Pump Motor: Use auxiliary relays, correct gauge wires, and 115/230VAC breakers to supply power to the pump motors. Refer to the installation manual of the equipment being used for complete installation requirements, drawings, and special notes for proper installation.

Pump Requirements

The Bennett 3K dispensers must have firmware equal to or better than 210 – 044.

It must be set to 485 communication, and each fueling point must be addressed in the pump's CPU.

It DOES NOT need a pulser interface option to communicate with the console. The firmware at or above 210 allows the pump and console to “talk” back and forth about current pricing, preset / prepay sale amounts, handle and sale status.

You may wish to connect only one set of data wires at a time to the EZ system. All of the dispensers will talk basically over the same two wires. Polarity or other wiring issues at one pump may cause a system wide communication failure.

Also, if two fueling points are set to the same address position, say # 2, the console will show communication with fueling point 2, but will not be able to control the pump properly. Prices may be sent to one dispenser, but the handle switch or grade select button may have no effect at the console as we will be receiving mixed messages. One pump will reply that its handle switch is lifted while the other with the same fueling point # will reply that its handle switch is hung up etc.

INSTALLING THE PETROSMART EZ CONSOLE

1. Mount all in Make sure that all system component connections and cables are properly assembled before turning on the power to any of the components.
2. Interconnect boxes near the wire trough, or where the conduit from the pumps/dispensers enters the building.
3. Place the console in a location that allows an unobstructed view of all fueling positions at the site.




Fig. 7. Back View of the PetroSmart EZ Console

Cable Connections

The connection between the PETROSMART EZ console and the interconnect box marked “DISPENSER CONTROL” is made via a 25 foot round cable having 15-conductors and DB-15 type connectors. Connect this cable at the connector marked PUMP CONTROL on the back of the EZ console to the connector labeled “2” on the front pan of the dispenser IC Box.

Longer cables are available to fit the particular needs of the installation site. The maximum recommended distance between the PETROSMART EZ Console and the PETROSMART EZ, “DISPENSER CONTROL” interconnect box is 500 feet. Consult TMS for prices and availability.

A connection is made between the IC Box back pan to the front pan is made via a 3 foot round cable having 15-conductors and DB-15 type connectors to the right most connection labeled “3” or the right most connection when the door is closed.

Refer to the PetroSmart EZ console, programming/operators guide on how to program the console.

Important Notes:

1. TURNING THE SYSTEM OFF: It is not recommended or necessary to turn OFF the dedicated system breaker that supplies power to the PETROSMART EZ IC boxes during the time the store/station is closed. Simply turning the console OFF/ON key to the OFF position after all hoses have been de-authorized, along with following the dispenser power down sequence, will prevent fuel from being dispensed.
2. All + and – data wire connections between the PETROSMART EZ IC boxes and the dispensers must be 18 gauge or larger.
3. All AC wires must be 14 gauge or larger.
4. Use cable ties to keep the data cable in place from the console to the interconnect box if conduit is not used.
5. If the PETROSMART EZ cable is put through a conduit, use 2" minimum to allow room for the connectors on the cable. Do not cut connectors from the PETROSMART EZ cable to use smaller conduit. Do not put PETROSMART EZ cable conduit underground. PETROSMART EZ data cables are not designed to operate under these conditions and will not be covered under warranty.
6. Do not use wire nuts on any grounding connections. Make all connections with compression connectors (crimp or split lug).
7. If the console or dispenser power comes from a sub-panel, all ground wires must end at the main electrical service panel ground.
8. There must be no more than 1-ohm resistance between Neutral and Earth Ground.
9. Do not use old or used wire for dispenser wire connections.
10. Use rigid metal conduit only. Do not use PVC conduit.
11. Do not route mercury vapor, canopy light wiring, or other unrelated wiring through the dispenser-wiring conduit.
12. Auxiliary relays or contactors **MUST BE** used in the motor circuit! Refer to the installation manual of the dispenser for complete installation requirements, drawings, and special notes.
13. Wiring for dispensers, PETROSMART EZ for BENNETT IC box, and other control boxes should all be on the same phase from the service panel, or erratic operation/communication could result.
14. In the interest of everyone's safety, all persons involved in the operation of this system should be made aware of a proper power-down sequence for all components used to dispense flammable products.

SPECIFICATIONS

DIMENSIONS

PETROSMART EZ Console	8" W x 4-1/2" H x 9-3/4" D
PETROSMART EZ Dispenser IC Box for	10" W x 11-1/2" H x 4-3/4" D
PETROSMART EZ DPT credit card module IC Box	10" W x 11-1/2" H x 4-3/4" D

WEIGHTS

PETROSMART EZ Console	7 lbs.
PETROSMART EZ IC Box for BENNETT	8 lbs.
PETROSMART EZ Cable (25 ft)	2 lbs.

NOTE: The above weights do not include shipping cartons or packing materials.

PERIPHERAL INTERFACE INSTALLATION

In compliance with the UL regulations and standards that apply to the Petroleum Industry, the following information establishes installation parameters for the use of peripheral equipment with the PETROSMART EZ Control Console.

1. Any peripheral equipment must be UL listed.
2. Any peripheral equipment must have an Electronics Industry Association (EIA) Standard RS-232C or RS-422A communications interface (whichever is appropriate for the application).
3. Any peripheral equipment must not be installed in or above a hazardous location.
4. The peripheral interconnection cable must be either UL Style 1061 or 2462 suitable for interconnection of electronic equipment.

WARRANTY AND SERVICE INFORMATION

WARRANTY AND LIMITATIONS OF REMEDIES

TMS warrants that new equipment manufactured by TMS shall be free of defective parts and workmanship for a period of two (2) years, commencing on the day of invoice from TMS. TMS salesmen, distributors, representatives, or agents may have made oral statements about the equipment described herein. Such statements do not constitute warranties, shall not be relied on by the buyer and are not part of this contract of sale. **EXCEPT AS SET FORTH ABOVE, TMS MAKES NO WARRANTY, EXPRESS OR IMPLIED, TO BUYER OR ANY OTHER PERSON AS TO THE EQUIPMENT'S FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, DESIGN, CONDITION, OR ANY OTHER ASPECT OF THE EQUIPMENT WHICH IS THE SUBJECT OF THIS CONTRACT OF SALE, ITS COMPONENTS, WORKMANSHIP AND MATERIALS; BUYER TAKES AND ACCEPTS THE EQUIPMENT AS IS.** By reason of his acceptance of delivery of the equipment, Buyer agrees that the equipment is in proper operating order, conforms to the Buyers specifications and the terms and conditions of the contract of sale, and has accepted the equipment in its condition on delivery as the equipment described herein.

Buyer's remedies for damages due to breach of the warranty set forth herein shall be limited to repair or replacement of non-conforming goods or parts within the aforesaid time period of two (2) years. **LABOR, TRANSPORTATION, AND TRAVEL ARE NOT COVERED BY THE WARRANTY.** The parties agree that the Buyer's sole and exclusive remedy against TMS shall be for the repair or replacement of defective parts or goods as provided herein. Buyer agrees that no other remedy, including but not limited to incidental or consequential damages for lost profits, lost sales, injury to persons or property, or any other incidental or consequential loss, shall be available to it. TMS further disclaims liability for any loss, damage or injury to any person as a result of any defects, latent or otherwise, in the equipment whether arising from TMS negligence, application of the law of strict liability, or breach of warranty.

This warranty is automatically void and of no effect in the event of defect, damage, injury or failure of the equipment due to any of the following causes: Acts of God; improper installation; failure to maintain the equipment in accordance with TMS instructions; use of the equipment in any manner other than the use for which TMS has designed and intended the equipment; attempt to install, repair or replace the equipment by any person other than a TMS authorized employee or agent; modifications or changes to the equipment of any kind or nature; excessive or improper usage and electrical burnouts or surges.

This writing contains the final expression of the parties' warranty agreement and is a complete and exclusive statement of the terms of the agreement. Parol evidence shall not be admissible to supplement, modify or add to the terms hereof for any purpose.

WARRANTY PERIOD

New components manufactured by TMS are guaranteed as outlined in the WARRANTY AND LIMITATIONS section for a period of two years. This guarantee consists of a 12-month FACTORY SERVICE WARRANTY plus a 12-month grace period allowed to distributors to cover shelf time, exchanges with their customers for repairs, etc. **The warranty period starts from the date of shipment from TMS.**

Remanufactured components from TMS are guaranteed for a period of one year, beginning from the date of shipment from TMS.

Every new or remanufactured TMS component has a date code that reflects the date of shipment from the factory; this date code is used to determine the warranty period. **Any TMS product returned for service without a date code or with a date code which has been altered for any reason will be considered out of warranty.**

This warranty period does not apply to printers and accessories, or other items which are not manufactured by TMS; those components are warranted for 90 days.

ABOUT OUR WARRANTY

The TMS FACTORY SERVICE WARRANTY is specifically limited to parts and equipment; **it does not cover service travel and labor charges.**

The warranty does not apply to parts and equipment which have been damaged by accident, lightning, physical abuse, mis-wiring, misapplication, or improper operation.

Our service policy is to repair and return warranted equipment, or to exchange for re-manufactured components. **We do not send out new parts and take back old or used ones at no charge.**

WARRANTY REPAIR POLICY

During the warranty period, defective TMS components may be returned freight-prepaid to Triangle MicroSystems, Inc. TMS will repair or replace, solely at our discretion, at no charge, and return via ground shipment freight-prepaid, such components that are judged to be defective in materials or workmanship. **Please note that a repair under warranty does not extend or renew the original warranty period.**

WARRANTY EXCHANGE POLICY

In some cases, we are willing to ship a replacement component in advance for warranty exchange. In this event, the component will have the same date code as the unit it will replace. **Any request for advance shipment of a warranty exchange component must be accompanied by the date code on the defective unit to be returned for credit.** If the replacement component that we ship has a new warranty, we will issue credit **only for the unused portion of the warranty** on the component returned to us.

Advance shipment of a warranty exchange console will include a \$50.00 cosmetic charge to cover the cost of cleaning, replacing the overlay, etc.

NON-WARRANTY REPAIR POLICY

When we receive an out-of-warranty component for service, we may routinely offer to exchange it for a remanufactured, re-warranted unit.

NON-WARRANTY EXCHANGE POLICY

As stated above, we may routinely offer to exchange out-of-warranty parts for remanufactured, re-warranted units. In many cases, we are willing to ship remanufactured components with the understanding that out-of-warranty parts will be returned as a core at a later date. You will be billed for the price of the remanufactured equipment and the core **MUST** be received within 30 days. These cores **must be returned within 30 days**; otherwise, customer will be billed the Core charge.

ABOUT EXCHANGES

When returning a component to TMS for credit against an exchange unit that we have sent to you in advance, **please reference the RA number** (Return Authorization) printed on the packing slip that comes with the exchange unit. This helps us to identify the item and to expedite the credit. When no RA number is referenced, there is a possibility that the part will be repaired or exchanged and returned to you, since we may not know that it is a credit return. Please help us to avoid this unnecessary situation.